

LAA-5 Pinout,





<u>J1- Power Interface : 2Pin 5.08mm Centers Phoenix</u> Mating Connector: OnShore# EDZ95002

Digi-Key# ED1717

- 1. Main power return
- 2. Main V+ power input

<u>J2 - Actuator Connector: 25-Pin Female D-Sub</u> <u>Mating Connector: NorComp# 171-025-102-001</u> Digi-Key# 225M

- 11. /Fault
- 12. /Inhibit
- 13. M2 (Motor output 2)
- 23. /Fault return
- 24. /Inhibit return
- 25. M1 (Motor output 1)

<u>J3 - Controller Connector: 25-Pin Male D-Sub</u> <u>Mating Connector: NorComp# 171-025-202-001</u> <u>Digi-Key# 225F</u>

- 11. /Fault
- 12. /Inhibit
- 13. AVIN (analog voltage in +/- 10V)
- 23. /Fault return
- 24. /Inhibit return
- 25. AVGND (Analog voltage ground)

Pins J2.11 and J3.11 are internally connected.

Pins J2.12 and J3.12 are internally connected.

Pins J2.23 and J3.23 are internally connected.

Pins J2.24, J3.24 and J3.25 are internally connected to the main power ground.

All undefined pins are straight through connector to connector, pin 'n' to pin 'n' circuits.

What are the PIN-OUTS for the LAA-5?

LAA-5 AMPLIFIER - ACTUATOR CONNECTOR, FEMALE (OUTPUT TO ACTUATOR)

Pin Number	Description	TOR, FEMALE (OUTFUT TO ACTUATOR
1	+5V	5 VOLTS TO ACTUATOR FROM CONTROLLER
2	5 VOLT RETURN	0 VOLTS TO ACTUATOR FROM CONTROLLER
3	PHASE A+	PASS THROUGH FROM AMPLIFIER
4	PHASE B+	PASS THROUGH FROM AMPLIFIER
5	INDEX+	PASS THROUGH FROM AMPLIFIER
6	OVERTEMPERATURE	PASS TROUGH FROM ACTUATOR
7	OVERTEMPERATURE RTN	PASS TROUGH FROM ACTUATOR
8	LIMIT+	PASS TROUGH FROM ACTUATOR
9	LIMIT- RETRACT	PASS TROUGH FROM ACTUATOR
10	LIMIT RETURN	PASS TROUGH FROM ACTUATOR
11	FAULT	OUTPUT SHUTDOWN BIT OPEN COLLECTOR OPTO
12	INHIBIT	AMP ENABLE BIT, LED OF OPTO
13	MOTOR+	POWER TO ACTUATOR COIL
14	PHASE A-	PASS THROUGH FROM ACTUATOR
15	PHASE B-	PASS THROUGH FROM ACTUATOR
16	INDEX-	PASS THROUGH FROM ACTUATOR
17	NOT USED	
18	NOT USED	
19	NOT USED	
20	NOT USED	
21	NOT USED	
22	ROTARY COARSE HOME	
23	FAULT RETURN	
24	INHIBIT RETURN	
25	MOTOR-	POWER RETURN FROM COIL

Pin Number	Description	
1	+5V	5 VOLTS TO ACTUATOR FROM CONTROLLER
2	5 VOLT RETURN	5 VOLTS TO ACTUATOR FROM CONTROLLER
3	PHASE A+	PASS THROUGH FROM AMPLIFIER
4	PHASE B+	PASS THROUGH FROM AMPLIFIER
5	INDEX+	PASS THROUGH FROM AMPLIFIER
6	OVERTEMPERATURE	PASS TROUGH FROM ACTUATOR
7	OVERTEMPERATURE RTN	PASS TROUGH FROM ACTUATOR
8	LIMIT+	PASS TROUGH FROM ACTUATOR
9	LIMIT- RETRACT	PASS TROUGH FROM ACTUATOR
10	LIMIT RETURN	PASS TROUGH FROM ACTUATOR
11	FAULT	OUTPUT SHUTDOWN BIT OPEN COLLECTOR OPTO
12	INHIBIT	AMP ENABLE BIT, LED OF OF OPTO
13	V. SERVO COMMAND	+/- 10 VOLT FROM CONTROLLER
14	PHASE A-	PASS THROUGH FROM ACTUATOR
15	PHASE B-	PASS THROUGH FROM ACTUATOR
16	INDEX-	PASS THROUGH FROM ACTUATOR
17	NOT USED	
18	NOT USED	
19	NOT USED	
20	NOT USED	
21	NOT USED	
22	ROTARY COARSE HOME	
23	FAULT RETURN	
24	INHIBIT RETURN	
25	V RETURN SERVO COMMAND	+/- 10 VOLT FROM CONTROLLER

What type of software do I need? What are the specifications for (LAA-5) Amplifier?

Specifications for (LAA-5) Amplifier

Supply Voltage:	11-48 Volts DC
Output Current	3 Amps Continuous; 6 Amps Peak
Nominal Input Voltage Control Range:	±10 Volts
Maximum Input Voltage:	±15 Volts
Quiescent Current:	Approximately 30mA
Enable Input Current:	Approximately 2mA
Overtemp Output Current:	0.8V at 2mA
Input/Output Gain:	Approximately 0.6 Amps/Volt
Input/Output Linearity:	Approximately ±6% over the entire operating range for an output current of 1 to 3 amps
Operating Frequency Band:	>1KHz
Switching Frequency:	Approximately 55KHz
Operating Temperature Range:	0°C <= To <=50°C
Storage Temperature Range:	-40°C <= Ts <=125°C
Input Impedence:	>2K Ohms

- -The SMAC LAA-5 amplifier is a PWM style amplifier.
- -The inhibit pin input is 9 volts and must be grounded for amplifier to shut down.
- -To allow the amplifier to operate the pin can just be left floating.
- -The yellow fault light is on when the amplifier becomes overheated.
- -The fault pin can switch up to 30 volts at 10ma. This switch is normally open. If you place a 5 volt, 10ma current limited signal to the Fault output (pin 11) it will go to about 0 volts when an overheat condition is reached.
- -Fault (10), fault return (23), inhibit (11), servo command (13), servo return (25) are the only pins that are used for the amplifier. All other pins are flow through only. These are used to make cabling easier.

What size power supply should I get?
The following are minimum requirements. For exact requirements contact the factory.

24 VDC	LINEAR	2 amps
	ROTARY (1624 SERIES)	1 amp
ACTUATORS	ROTARY (2342 SERIES)	2 amps
48 VDC	LINEAR	2 amps
	ROTARY (3557CR SERIES - 1Nm)	3 amps